



## WARNING

**DO NOT USE THIS BENCH IF ANY DAMAGE HAS OCCURRED**

**DO NOT USE ANY SAW OR APPLY ANY LOAD TO THE BENCH WHICH MAY CAUSE INSTABILITY**

**AN ADJUSTABLE STABILIZING LEG CAN BE PURCHASED FOR WIDER LOADS OR BIGGER SAW TYPES**

## DROP-SAW BENCH - INSTRUCTIONS

- 1.** Fold out both legs of the Saw Bench into the fully open position.
- 2.** Saw Bench must be positioned on a flat level surface.
- 3.** Fit Platform.
- 4.** Place the Drop-Saw on top of the aluminium Platform.
- 5.** Adjust the height of the Platform by turning the four Nylock nuts provided so as the saw table is level with the channel top.
- 6.** Align the fence of the saw with the outer edge of the 150mm wide saw bench channel top by using a straight edge.
- 7.** Drill at least 2 x 10mm holes through the base of the Drop-Saw and through the aluminium Platform.
- 8.** To bolt the Drop-Saw down, use at least 2 x 10mm hex bolts with Nylock nuts and tighten.
- 9.** To secure the Platform to the Bench use one wing nut on each of the four height adjusting rods.
- 10.** To fit extension, lift to 45°.

**TOMMY TUCKER  
TRESTLES**

**AND PLANK FACTORY**

8-10 Kenway Dr. Underwood, Q. 4119

**(07) 3290 2705**

Fax: (07) 3290 0155